

Bike-Quip: Installation Guidelines - ST1300 Sat Nav Mount

Please read BEFORE attempting to fit this accessory.

Preparation: Protect the front end of your fuel tank with a towel or similar. Spray the two existing handlebar fixings (the two which are closest to your fuel tank) with WD40 or similar, as they can be very difficult to remove.

1. With a small 'sharp' ended screwdriver, prise off the 2 chromed plastic screw covers. Be gentle in this task as these plastic covers can break quite easily. Put these to one side for use later.
2. Remove the two screws you have now exposed and put these safely to one side - in case you ever want to remove your Sat Nav Mount.
3. Your Sat Nav Mount is sent to you with two transit nuts. Remove these nuts and dispose of them as they are not required.
4. Keep the Sat Nav Mount assembled in the same way as you received it. Carefully screw each fixing in to place carefully – thus avoiding getting a cross threaded problem! Do each screw up a little at a time until you have a secure fixing on each screw. During this whole fixing procedure – make certain that each of the 2 s/steel spacers are seated squarely at both their tops and bottoms.
5. Replace the two chromed plastic covers. If necessary, push these plastic covers fully home with a small piece of square or round wood (about 1/4" diameter) to avoid damaging them.
6. Some people remove the sat nav ball and apply Loctite to its thread - to reduce the chances of it being stolen.

Ride Safe!