

Bike-Quip: Installation Guidelines – Resin Badges

If replacing the original Honda ‘transfer type’ of Pan badges, these can be easily removed by applying GENTLE heat to them.

1. Ensure you remove ALL traces of adhesive.
2. The surface to which you are going to apply these badges.... MUST be thoroughly clean and smooth.
3. I strongly recommend you take great care in positioning each badge correctly (**level and upright!!**).
4. **HONDA V4** (Mk2) badges have small markings at the 3,6,9 and 12 o’clock positions to assist you.
5. Take great care to avoid air bubbles.
6. **WARNING:** To remove these badges and then to re-apply them will probably result in the metallic foil becoming damaged!
7. To remove them permanently – apply gentle heat first (to soften the adhesive).
8. In summary: Take great care in applying them and don’t rush – this will lead to you doing a professional job.

Ride Safe!